

Ridekick tires are heavy duty tires that last for over 1,500 miles, so a few tricks will help remove them from the rim.

Deflate the tube. Insert a tire iron. Before trying to prys it off, go to page 2.



First move the tire bead in to the center of the rim.

In a few places along the rim, press the side of the tire in and away from the edge of the rim.

This will provide some slack to aide in removing the tire.



Then you can pry up the tire iron and you can see how the tire bead moves into the center of the rim.

Be careful to not pinch the inner tube with the tire iron!



Use a second tire iron to remove the tire bead around the rim. Then proceed normally.



After replacing the inner tube, be careful to not pinch the inner tube with the tire iron!

When re-inflating, be sure to massage the tire so the bead seats evenly on the edge of the rim so you get a smooth ride.