


These small wheels have a little space for the tire inflator.



The standard tire pump nozzles are too large

These compact nozzles work well.





Therefore, a valve stem extender is included in your trailer.



Remove the cap, screw it on to the stem, and any Schrader pump nozzle will work.

Some people choose to leave it on (with the protective cap) so it's ready anytime. Others will stow it in the trailer.

